


## Temperature Controller for Charcoal Smoker Quick Guide Ver 1.2

This temperature controller is for Charcoal Smoker. To operate it, connect the 12VDC power adapter to the terminal 1 and wall outlet. Connect the fan connector to terminal 2. The polarity for this socket is center pin positive (+), outer collar negative (-). Connect the K thermocouple to the terminal 3. Please note that thermocouple connector also has polarity. The wide blade should go to wide slot.



- ① POWER-12V Power supply input
- ② OUT- Fan control output
- ③ INPUT-Temperature probe input

Figure 1. Controller connector identification.

### Application tips.

- 1) The PID parameters are optimized for Charcoal smoker. Users don't need to change them. If you need further information about how to fine tune the controller, please refer to the instruction manual.
- 2) To set target temperature:  
There are two ways to set the target temperature.
  - a. During the normal operation mode, press  $\wedge$  or  $\vee$  once to switch the display from process value (PV) to set value (SV, or target temperature). The display will start to blink. Press  $\wedge$  or  $\vee$  again to increase or decrease the SV. When finished, wait 8 seconds and the setting will take effect automatically (the display will stop blinking).
  - b. Press SET key once. Use  $>$ ,  $\wedge$  and  $\vee$  keys to enter code 0001. Press SET key to confirm, then the display would be SV (Su). Press SET key again to display the SV setting. Use  $>$ ,  $\wedge$  and  $\vee$  keys to enter the new SV and press SET to confirm. Press  $\vee$  key to change the display to END. Then, press SET to exit. You can also ignore the steps after confirmation of SV. The controller will return to normal operation mode if no key is pressed for 1 minute. Figure 2 is a detailed flow chart that shows how to set the SV.
- 3) To set alarm:  
The controller offers two alarms that can be set to turn on the buzzer at specific temperatures. The first alarm is controlled by parameter AH1 and AL1. The initial setting will turn on the buzzer at 250°F and off when temperature drops below 249°F. The second alarm is controlled by parameter AH2 and AL2. The initial setting of the second alarm is deactivated. It can be set as low alarm to send warning when charcoal is low.  
AH1 and AH2 are the temperature to turn buzzer on; AL1 and AL2 are the temperature to turn buzzer off. When  $AH1(2) > AL1(2)$ , the alarm is set for absolute high alarm, When  $AH1(2) < AL1(2)$ , the alarm is set for absolute low alarm, When  $AH1(2) = AL1(2)$ , the alarm is deactivated.  
For example, if  $AH1=250$ ,  $AL1=249$ , when the temperature goes up to 250°F, the buzzer will be

on; when the temperature drops down to 249°F, the buzzer will be off.

If AH2=180, AL2=185, when the temperature drops down to 180°F, the buzzer will be on; when the temperature goes up to 185°F, the buzzer will be off.

User can press the shift key (>) to temporarily silence the buzzer sound alarm 1 (AH1 and AL1).  
NOTE: Alarm 2 (AH2 and AL2) cannot be silenced. The alarm will buzz again if the alarm set temperature is reached again. If you use the low limit alarm function, we suggest you set AH1 and AL1 as the low alarm because the low limit alarm needs to be silenced more frequently than the high limit alarm. This is a useful function if the low alarm is turned on when starting the controller from cold. However, if you choose to use the alarm AH2 and AL2 as the low temp alarm, turning on the temperature controller after cooker internal temperature has passed the temperature set for AH2 will prevent the low temperature alarm from sounding on startup. To permanently deactivate the alarm, set AH1=AL1 or AH2=AL2. Please see flow chart below on how to set the value.

### New Approach for controlling the temperature

Recently we found that one of the optional functions not listed in the manual actually works great for some situations that is difficult to control by the default setting.

What you need to do is:

1) Enter code 0037, then set "Caty" to 1. (the original value was 0), set SF=20 (Don't change the bb parameter).

2) Then, enter code 0036. Change "ot" from 7 to 20. The P, I and D settings should be kept unchanged (the same as the initial setting).

This approach is particular effective to overcome the temperature overshoot problem.




Figure 2. Flow charge of how to set the target temperature (SV) and alarms.